

ARCORA®


anik®350 DUO BRUSH



EN

USER MANUAL

CARPET & HARDFLOOR CLEANING MACHINE



www.arcora-group.com

ATTENTION!

Do not use the machine without having read the user manual.

PAY PARTICULAR ATTENTION TO THE FOLLOWING POINTS REGARDING OPERATION, USE AND MAINTANENCE:

The machine may only be used by someone who has been instructed in its use and given authority to do so. The electrical plug must be disconnected from the main electricity supply before cleaning, servicing the machine and before changing parts thereof. Make sure that the power cord is not damaged in any way by running over it, squashing or tearing it, etc. The cable must only be replaced by spare part number #G46 or a DIN 57.281 part 402/VDE 0281 part 402 05W 3x1 mm² cable.

All connections of mains supply cable must be protected at least against water splashing. The machine must be fitted with a power safety switch with a capacity of 10 amps or a 10 amps fuse. This appliance is not to be used or stored outdoors in wet conditions and is not suitable for working with or picking up hazardous substances.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

TECHNICAL DATA	ANIKO 350 DUO BRUSH
Motor	600 W
Brush Rotations	483 U/pM
Soundlevel at 0,5 m	57,8 dB
Weight	21,3 kg
Length	40,5 cm
Width	28,5 cm
Height without/with handle	23 cm/117 cm
Cable lenght 230 V/110 V	10 m/15 m
Dirt water capacity	2,8 l
Coverage carpet	up to 100 m ² /h




EN **ASSEMBLING**

Attach the handle on the connection cone of the machine and lock them with the snap-in.

Attach the power cord to the clips on the handle to protect it.

Attention: do not leave the machine sitting on the brushes when not in use.



EN **MOUNTING OF RENOVATOR AND BRUSHCOVERS**


1. Put the Renovators (receptacles) or the brushcovers on the mounting hooks at the bottom side, then press them against the machine to lock them.
2. For removing the Renovator or brushcovers push the middle button to release them.



EN **STARTING THE MACHINE (SWITCH ON/OFF)**

Connect the power cord of the machine to the main power supply.

1. First push the foot lever, then pull the handle towards you to start the machine.
2. To stop the machine put the handle completely back in to upright position.



EN **MOTOR SAFETY SWITCH**

To reset it, wait approx. 30 seconds. Then push it back into place using a pointed object like a pen.

BRUSHES

5a



EN

CHANGING OF BRUSHES

Use original brushes only.

Attention: before changing the brushes disconnect the power cord.

1. Position the machine sideways, push the brush axle in on one side, pull it out from the other side.
2. Remove brushes.
3. Put in new brushes and insert brush axles from the top.

Attention: Do not use force. For inserting the brush-axle without force, gently turn axles and brushes while pushing the axle down.

5b



EN


BRUSHES

Before use, check the brush compatibility on the carpet.

Attention: limited suitability for wool and high-pile carpets (recommended brush: soft).

a: soft | b: standard | c: stiff | d: extra stiff

6




EN

MACHINE CLEANING

Disconnect the power cord, then remove the brushes (see picture 5.a changing of brushes).

On completion of any carpet cleaning, remove the remaining compound and dirt with the cleaning brush. After any hardfloor cleaning, clean the machine with pure water.

7



EN


REPLACEMENT OF DRIVE GEARS

Disconnect the power cord.

Take off gear cover (#G33).

Remove the allen screw of the gear you wish to change. Replace the gear and lock it with the allen screw. Close the gear cover.


CARPET CLEANING



EN

CARPET CLEANING

1. Attach the Renovators to remove all dry soil out of the carpet.
2. Prespray and/or sprinkle compound. Attach the brushcovers and brush areas in multiple directions.
3. Attach Renovators and remove compound.



EN

HARD FLOOR CLEANING

Cleans profiled floors, PVC, tiles, stone, natural stone, rubber and non-slip safety floors.

1. Mount brushcovers. Apply cleaning liquid onto hard floor. Scrub with the machine.
2. Mount Renovators. Collect the dirty water with the machine. When full, take off the Renovators, empty them and dispose of the contents according to local regulations.

WARRANTY!

EN

WARRANTY

We repair free charge damages or defects of the machine which are due to faulty workmanship, if they are claimed immediately after their detection and within 6 month after delivery to the final costumer. The warranty does not include wear and tear parts such as brushes or gears. We reserve the right to either repair the faulty element or replace the faulty element. Further claims, in particular claims for damage going beyond the machine itself, are not included in this guarantee unless such a liability is explicitly foreseen by legal national standards. If cleaning agents others than original products are used, we do not accept any liability. Consequential damages to carpets and furniture elements are not covered by this warranty.

MACHINE NO:

DATE OF DELIVERY:

ARCORA®

EC DECLARATION OF CONFORMITY/ EG KONFORMITÄTSERKLÄRUNG

We hereby declare that/*Hiermit erklären wir, dass*

PRODUCT/PRODUKT:

Carpet & Hardfloor Cleaning Machine/
Teppich- und Hartbodenreinigungsmaschine

TYPE/TYP: Carpet & Hardfloor Cleaner

MODEL/MODELL: ANIKO 350 DUO BRUSH

conform to the relevant fundamental safety requirements of the appropriate EC-directives./*den einschlägigen grundlegenden Sicherheits-Anforderungen der EG-Richtlinien entsprechen.*

Relevant EC-Directives/Relevante EG-Richtlinien:

Machinery Directive 2006/42/EC:

EN 60335-1:2012 + A11:2014

EN 60335-2-10:2009-04-01

Low Voltage Directive 2006/95/EC:

EN 62233:2009-01-01

Electromagnetic Compatibility (EMC) Directive 2004/108/EC:

EN 55014-1:2012-06-01

EN 55014-2:2009-08-01

EN 61000-3-3:2014-04-01

EN 61000-3-2:2015-04-01

ARCORA International GmbH
Marsstrasse 9
85609 Aschheim near Munich
Telephone: +49 (0)89 / 14 33 29 3- 0
Telefax: +49 (0)89 / 14 33 29 3- 29
Email: info@arcora.de
Web: www.arcora-group.com



www.arcora-group.com

**PRIME
CLEANING
SUPPLIERS**

COMPLETE CLEANING SOLUTIONS®

www.primecs.co.za

WESTERN CAPE - 021 551 4570
GAUTENG - 086 111 6008
GARDEN ROUTE - 044 878 1356
EASTERN CAPE | SM SALES - 041 365 2886
MBOMBELA | SM SALES - 013 010 1247
KZN | PAPER LOGIC HYGIENE - 032 944 7750
FREE STATE | IDFS - 051 448 1230

CLEANING CHEMICALS/ DISINFECTANTS ▼ PAPER PRODUCTS/DISPENSERS ▼ CLEANING SUNDRIES
All product names, © Registered Trademarks are property of their respective owners © 2024 - All Rights Reserved